

REMOTE CONTROL CODING INSTRUCTIONS

Model: SEIP TM60/TM80



Gryphon Garage Doors 1300 959 554

To Delete All Coding:

1. Stand behind motor, facing garage door.
2. Unscrew motor casing. Screw is located at back of cover in centre. Casing will hang down.
3. You will now be able to see the green circuit board.
4. Press Learn button and hold in for 15 seconds. Wait a few moments then proceed as below to recode your remote.

Coding In:

1. Stand behind motor facing garage door.
2. Remove rear electrical casing from the motor – you will see part of the circuit board.



3. Hold 'Learn' button until light at front of motor flashes and release – is found on the right hand side of board
4. Press and hold one of the buttons on the Remote/handset for 3-4 seconds.

Handset will now be coded in.

If you have any questions, please do not hesitate to contact the office.